



User Manual

**Thermal Network Camera,
336x256, 25Hz, Audio,
Composite, PoE, IP67**

ITB-7SF0075M0A

ITB-7SF0013M0A

ITB-7SF0019M0A

ITB-7SF0035M0A

Table of content

Parts supplied	5
Part names	6
Installation instructions	7
Pan & Tilt adjustments	8
Power supply connections	10
General Description	11
Log In Menu Setup	12
Further information	12
Full Menu Setup	13
Setup Menu Table	13
LIVE VIEW	15
Player control & Display	15
Video stream & Protocol	16
PTZ Control	16
PLAYBACK	17
Event search	17
Timeline search	17
SETUP	18
Information	18
Video & Image	18
Audio	29
Record	30
Event	32
System	46
USER MANUAL	56
Troubleshooting	57

Safety instructions

General safety instructions

- Before switching on and operating the system, first read this safety advice and the operating instructions.
- Keep the operating instructions in a safe place for later use.
- Installation, commissioning and maintenance of the system may only be carried out by authorised individuals and in accordance with the installation instructions - ensuring that all applicable standards and guidelines are followed.
- Protect the devices from water penetration and humidity, since these can cause lasting damage.
- Should moisture nevertheless enter the system, under no circumstance switch on the devices under these conditions, instead send them for examination to an authorised specialist workshop.
- The system must never be used outside of the technical specifications, since this can destroy it.
- The device must be protected from excesses of heat, dust, humidity and vibration.
- When separating the system from the voltage supply, only ever use the plug to pull out the cable. Never pull directly on the cable itself.
- Lay the connecting cables carefully and check that they are not mechanically stressed, kinked or damaged and that no humidity can penetrate into them.
- In the event of a malfunction, please inform your supplier.
- Maintenance and repairs may only be carried out by authorised specialist personnel.
- The system must be isolated from the power supply before opening the housing.
- The device may only be opened by qualified service personnel. Unauthorised access invalidates any warranty claim.
- Connection cables should always be exchanged through Videor E. Hartig GmbH.
- Use only original spare parts and accessories from Videor E. Hartig GmbH.
- The housing should only be cleaned using a mild domestic cleaning agent. Never use solvents or petrol as these can permanently damage the surface.
- During installation, it is essential to ensure that the seals provided are correctly installed and that they are not displaced during installation. Damaged seals must not be installed and will invalidate any warranty.
- The installer is responsible for the maintenance of the enclosure as per the technical data, e.g. by sealing the cable outlets with silicone.
- Wire end ferrules should be used when shortening the flexible connection cables.
- The devices may only be operated in the temperature range indicated in the data sheet and within the defined air humidity range.

Product - Specific Safety Instructions


- The camera may never be pointed directly at the Sun with the aperture open (this will destroy the sensor).
- It is unavoidable that during manufacture and to a certain extent during later use, humidity will be present in the ambient air within the device's housing. In the event of large temperature fluctuations, this humidity may condense inside the housing.
- To avoid this condensation inside the very tightly sealed housing, the manufacturer has inserted silica gel sachets in the housing of the various camera types.
- It is however a physical given, that these silica gel bags will reach saturation after a certain amount of time. They should therefore be replaced with new silica gel sachets.
- During installation, it is essential to ensure that the seals provided are correctly installed and that they are not displaced during installation. Damaged seals must not be installed and will invalidate any warranty.
- A multipolar, easily accessible isolation device should be installed in the proximity of the IR Spotlight, in order to disconnect the device from the power supply for service work.
- The earth connection must be made according to the low impedance requirement of DIN VDE 0100.
- Subsequent painting of the equipment surface can impair the function.
- Any warranty claim is invalidated by subsequent painting.
- A safety margin of > 1m from the spotlight must be maintained when viewing directly into the IR Spotlight in a darkened environment.
- Do not look directly at invisible LED radiation using optical instruments (e.g. a reading glass, magnifying glass or microscope), since this can endanger the eyes, LED Class 1M.
- Operation of the IR spotlight with a defective cover or during repair is prohibited.

Class A device note

This is a Class A device. This device can cause malfunctions in the living area; in such an event, the operator may need to take appropriate measures to compensate for these.

WEEE (Waste Electrical & Electronic Equipment)

Correct Disposal of This Product (Applicable in the European Union and other European countries with separate collection systems).



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Graphical symbols

Please pay attention to the safety instructions, and carefully read through this instruction guide before initial operation.




Important points of warning are marked with a caution symbol.




Important points of advice are marked with a notice symbol.

Parts supplied

- Thermal Camera
- Operating Instruction
- CD
- Mounting Template
- Cable Signal Sticker
- Plastic Anchor: 6 x 30mm (4x)
- Mounting Screw: 4 x 30mm (4x)
- Assembly Screw: 4 x 15mm (4x)
- Torque Wrench: 3mm (1x)
- Coupler for RJ45 Cable (1x)
- Video Sub-out Cable (1x)
- Wiring Connector: (1x)
- Easy Bracket




Part names




Installation instructions



CAUTION: The camera's base should be attached to a structural object, such as concrete, hard wood, wall stud or ceiling rafter that supports the weight of the camera. If necessary use appropriate mounting material (e.g. anchors) instead of the material enclosed with the camera.

1. Locate the mounting template at the installation position and drill the ceiling or wall if needed.  The easy bracket can not be installed on the ceiling.
2. Place the easy bracket on pre-drilled position and fix it through using mounting screws(4x30mm). Skip this step when an easy bracket is not installed.
3. Route the ethernet and power cable to the connecting place. Hook up the camera bracket with the easy bracket as illustrated below.
4. Fix the camera bracket through using assembly screws (4x15mm).
5. Set the camera's viewing angle.
6. Put the sunshield to the camera unit and tighten the sunshield-bolts.



CAUTION:


Extreme care should be taken NOT to scratch the window in front of lens.

Care should be taken the cable is NOT to be damaged, kinked or exposed in the hazardous area.



Pan & Tilt adjustments

- Unlock the screw on the camera bracket through using the torque wrench supplied
- Set the camera's viewing angle then lock the screw on the bracket.


1. Pan limit: Pan is limited to $\pm 90^\circ$.




2. Tilt limit: Tilt is limited to $0^\circ(2^\circ)$ min $\sim 90^\circ$ max. for wall(ceiling) installation respectively with reference to the wall(ceiling) when the inclination of camera module is 0° , that is, the image is aligned horizontally.



3. Inclination limit (Horizontal image alignment): Inclination limited to $\pm 90^\circ$ max.



Adjustment of viewing angle with a bracket




Power supply connections

Make sure the power is removed before the installation. Camera can work with either 24VAC or 12VDC, dual voltage power and PoE (IEEE Std. 802.3af). Primary and secondary grounds are completely isolated to avoid the possible ground loop problems.

1. Plug the network cable into RJ-45 Ethernet Port. If PoE is the unique power, there will be no need to connect Power terminal.
2. When DC12V or AC24V Local power is necessary, connect the low voltage (DC12V or AC24V) first, then plug the AC adapter to AC outlets to avoid an improper reset from power jitter and a damage from the surge voltage when no load.

i When PoE and local dual power are connected at the same time, local power has priority.



Attach the Signal Assignment Sticker in a visible spot for wiring reference.

General Description


- Thermal Imager: Supporting FLIR TAU2 module
- ONVIF Conformance
- Zero configuration
- Cross Web Browsing (IE, Safari, Firefox, Chrome)
- Adaptive web resizing depending on layout & resolution of display device by RESPONSIVE WEB
- Increased usability for all PC, tablet and mobile
- Simultaneously H.264 & MJPEG (Triple streaming)
- ONVIF Event Mapping
- Slot for Micro SD memory card
- HTML5 playback
- Video output: Network RJ-45, CVBS(Sub-out)
- Internet: 10/100 base-T, RJ-45
- Sharpness (DDE), Palette, FFC Warn, Auto Preset, Contrast, Brightness, Filter, SSO, ACE, FFC, Spot Meter, ISO thermal, D-Zoom(16x), Privacy mask, Mirror/Flip, VerticalView, VCA (Video Contents Analysis)
- USB Communication
- IP & CVBS BNC output
- CVBS Video Sub-out port for easy installation & maintenance
- Circuit protection against faulty connection in power polarity
- Isolated power supply against ground loop problem
- PoE(IEEE Std. 802.3af), AC24V/DC12V
- One touch 3-Axis bracket
- Built-in Fan & Optimized Cooling system
- Housing Color : Grey
- IP67 Protection

Log In Menu Setup

1. After the camera is connected to the network, start 'eneo Site Manager' tool (downloadable from www.eneo-security.com).
2. You will get a list of cameras connected to the local network. Highlight your camera in the list and open a context menu with a click of the right mouse button.
3. Select the „Set IP Address [dhcp / static]“ option to open a window for setting the cameras IP properties. When you are done click the „OK“ button to update the camera settings.
4. By default the camera is set to DHCP. If there is no DHCP server present in the network the camera will fall back to a default IP address after a while. In this scenario please only add one camera at a time to the network to avoid conflicts due to identical IP addresses.
The network camera's default IP address is: **192.168.1.10**.
5. Right clicking the device name in the eneo Scan Device tool will bring up the context menu. Use the 'Open Device Web Site' option to access the camera.
6. The web viewer login page will open up in your default web browser.
In case of Microsoft Internet Explorer install Active-X named VIDEOR E. Hartig GmbH according to the instruction at the bottom of the browser.
7. Use the default user name and password to log in.

Default user name: admin

Default password: admin



The screenshot shows the login interface for an eneo device. At the top, there is a header bar with the eneo logo on the left and a placeholder 'xxx-xxxxxxxxxx' on the right. Below the header, there are two input fields: the first is for the username, containing the text 'admin', and the second is for the password, represented by dots. Below these fields is a checkbox labeled 'Jump to setup'. At the bottom, there is a large orange button labeled 'Login'.

Further information

Make sure to always upgrade to the latest firmware version available from the eneo web site at www.eneo-security.com to receive the latest functionality for your product.

The manual, and other software tools are available on the eneo website at www.eneo-security.com or on the included CD.

Information on compatible video management software solutions can be found in the category **Videomanagement** at www.eneo-security.com.

Full Menu Setup

Setup Menu Table

Category	Menu	Configuration			
LIVE VIEW	Player Control	Pause, Snapshot, Speaker, Microphone, Record			
		Display (Window Fit, Full Screen, Custom)			
	Video Stream	Stream1, Stream2, Stream3			
	Protocol	HTTP, TCP, UDP			
	PTZ Control (*)	Zoom, Focus, Push AF			
PLAYBACK	Event Search, Timeline Search, Timeline Bar				
SETUP	Information	General, System Information, Open source Information			
	Video & Image	Source			
		Stream1/2/3, Snapshot			
		Image	Basic	Sharpness[DDE], Palette, FFC Warn, Enable flip image, Enable mirror image	
			OSD	Enable text OSD, Enable date&time OSD	
			AGC	Mode, Auto Preset, Contrast, Brightness, Filter, SSO, ACE, Plateau Level, Max Gain	
			FFC	Mode, Interval (FFC Interval, Low Gain FFC Interval), Temperature (Temp Change, Low Gain Temp Change)	
			Thermal	Spot Meter (Mode, Thermometer), Isothermal (Mode, Threshold Unit, Upper/ Middle/ Lower Threshold)	
			VerticalView	Mode, Rotation	
		Privacy Mask	Color, Name		
	Digital Zoom	Level			
	Audio	Compression, Sample rate, Bitrate, Input Volume, Output Volume, Audio auto activation on ONVIF access			

Full Menu Setup

SETUP	Record	Record	Overwrite when storage is full, Continuous record setting
		Schedule	
		Storage	Format, Remove, Storage Information
	Event	Triggers	Motion, VCA, Tamper, Alarm In, System, Manual, Network, Timer, Temperature
		Actions	Record, Alarm Out, E-Mail, FTP, Video Boost, Notification Server
		Rules	Event Processing, ONVIF Mapping
	System	Security	User, HTTPS, IP Filter, ONVIF, Video Stream, Export/Import
		Date & Time	Current Time, New Time, Time Zone, Date & Time Display
		Network	TCP/IP, DDNS, RTP, UPnP, Zeroconf, Bonjour
		Language	English, German , French, Polish, Finnish, Korean
		Maintenance	Maintain (Restart, Reset, Default), Upgrade, Setup Export, Setup Import
		Log & Report	Logs (Database Capacity, Search Condition, Log List), Report
USER MANUAL			
LOG OUT			


(*) Available only with the built-in Motor driven V/F lens version

Full Menu Setup

1. LIVE VIEW

Enter the live view menu on the Web Viewer.

■ Web Viewer description



A) Menu button: Click the button to show or hide the setup menu bar.

B) Model name: Show a camera model name connected.


C) Select Language: Set the web viewer language Deutsch, English or French.

D) Main setup menu bar: Set the camera or network functions.

E) Camera monitoring window: Display the currently connected camera view or function.

F) Log out and exit the web viewer

■ Player Control



① Pause : Pauses the live view.

② Snapshot : Captures the image in .jpg format with the current stream resolution.


③ Speaker : Enables Audio to be output to the audio out port.

④ Microphone : Enables Audio to be input from the audio input port.


⑤ Record :

(Available with the built-in Storage feature version only)
Records the live video in H.264 format into the equipped storage memory like SD, SDHC&SDXC with the selected video stream at the RECORD menu.

■ Display



Full Menu Setup



- ⑥ Window Fit : Resizes the live view display to fit along with the display window size.
- ⑦ Full Screen: Resizes the live view display to fit to the monitor resolution. ESC key returns to the previous view.
- ⑧ Custom : Selects the live view display scale, 0%~200%, by the control bar. 100% is original size.

■ Video Stream

Selects the video source stream to display the live view only.

■ Protocol


Selects the network protocol out of HTTP, TCP or UDP.

■ PTZ Control

(Available with AF version & the built-in motor driven V/F lens version only)

Full Menu Setup

2. PLAYBACK



■ Event Search


Playback display using the event list.

- Press the input bar to pop up EVENT DATE & TIME window and select the event TYPE.
- Click SEARCH button to show up EVENT LIST.
- Select the recorded event and click the play button at the bottom-left corner of the playback window.

■ Timeline Search

Playback display by Date & Time for continuous and event recording.

- Select the date in the SEARCH CALENDAR and then the hour & minute at TIMELINE BAR.




Full Menu Setup

3. SETUP

Enter the setup menu on the Web Viewer.

3-1. Information

Shows the overall information about the system such as Model name, MAC address, IP address, Zeroconf, IP address, Firmware version, Server time, Running time, CPU usage, Inbound/Outbound Bandwidth and Open source list.




General	
Model	XXX-XXXXXXXXXX
MAC Address	78:D5:48:05:05:1D
IP Address	192.168.0.12
Zeroconf IP Address	169.254.17.225
Firmware Version	3.2.X.X-XXX

System Information	
--------------------	--

3-2. Video & Image

3-2-1. Source


- **SIGNAL** : Set NTSC/PAL mode depending on TV system. Generally set to NTSC in 30Hz area and PAL in 25Hz area for the electrical power system of your country. Changes will restart the camera.



Source	
Signal	PAL
Mode	1280x720@25fps

Full Menu Setup

3-2-2. Stream



Stream

SETUP / Video / Stream Save

Stream1

Compression	H.264 High Profile
Resolution	1280x720
Frame rate	25
GOP size	25
Bitrate control	CBR
Bitrate [Kbps]	6000

• **Stream1, 2, 3**

- > **COMPRESSION** : Video compression codecs are available with H.264 profiles for all streams and additional MJPEG for stream3 only.
- > **RESOLUTION** : Each stream can have its individual resolution selected from its list.
- > **FRAME RATE** : Each stream can have its individual frame rate in fps selected from its list.
- > **GOP SIZE**: GOP (Group of Picture) defines the number of Intra-coded pictures (I frame) & Predictive-coded pictures(P frame) in H.264. I frame is a complete image while P frame is the predictive image data which can lower the image data dramatically between frames. GOP SIZE stands for the number of P frames between I frames. Too small GOP SIZE (too frequent I frames) can degrade the picture quality because the codec compresses the data strongly to maintain the bitrate. On the contrary, a little bigger GOP SIZE can improve the picture quality with the better quality for P frames if the network is in good condition. Too big GOP SIZE can make the longer black out or the broken image if the network quality is not good enough.
- > **BITRATE CONTROL** : Selects how to manage the bitrate.
 - **CVBR (Constrained Variable Bit Rate)**:
Provides the higher image quality with the optimal variable bitrate for the scene which has more moving elements in the image. It is not recommended when network is in heavy duty.
 - **CBR (Constant Bitrate)** :
Tends to keep the bitrate steady at the assigned bitrate within a very small variation. It is useful when the network is in very heavy use.

Full Menu Setup

> **BITRATE** : Indicates the transmission speed through the network and defines the overall picture quality along with the image resolution, frame rate, GOP size and the compression codec for H.264. A high value provides the higher image quality but the total sum of bitrates for the streams has to be considered in calculating the network duty.

• Snapshot


Capture the video from the camera and create JPEG image files to acquire the image information such as number recognition software.

> Type http://ip_address/cgi-bin/snapshot.jpg in the address bar and press ENTER.

> Check the setting for capture image resolution:

WEB Viewer→ Log in→ Main Menu→ Setting→ Video&Image→ Video Stream→ Stream3→ Compression: MJPEG (Resolution: 1280x720),
Snapshot→ Source : Stream3


※ To maximize the resolution of the captured image, set the Snapshot→ Source to 'Stream1'.



The screenshot shows the 'Stream3' configuration window. It has two main sections: 'Stream3' and 'Snapshot'. In the 'Stream3' section, the following settings are shown: Compression is set to 'MJPEG', Resolution is '640x480', Frame rate is '12.5', and Quality is '60'. In the 'Snapshot' section, the Source is set to 'Stream3'. All settings are displayed in a table-like format with dropdown arrows on the right.

※ If the error message '401 Unauthorized' pops-up:




WEB Viewer→ Log in→ Main Menu→ Setting→ System→ Security→ Video Stream to disable the check boxes.



The screenshot shows the 'Security' settings window, specifically the 'Video Stream' tab. There are three checkboxes listed: 'Enable RTSP authorization', 'Enable JPEG Snapshot authorization', and 'Enable JPEG/HTTP PUSH authorization'. A red circle is drawn around these three checkboxes, indicating they should be disabled.

Full Menu Setup

3-2-3. Image



Full Menu Setup

• Basic

> SHARPNESS [DDE]:

Dynamic Digital Detail Enhancement (DDE) sets edge enhancement dynamically.

Higher DDE settings will enhance the sharpness resulting in a very detailed but grainy picture, especially in high dynamic range scenes.

> PALETTE: Select Palette type, WhiteHot, BlackHot, Fusion, Rainbow, Globow, Ironbow1, Ironbow2, Sepia, Color1, Color2, IceFire or Rain.

> FFC Warn [frames] :

A blue square symbol at top-right corner informs prior to performing an automatic FFC operation. Displaying time can be set by the time frame of the number of video frames (33ms/frame in NTSC, 40ms/frame in PAL). Setting the FFC Warning to less than 15 turns off the warning.


> ENABLE FLIP IMAGE : Flips the image on horizontal axis (up and down).

> EABLE MIRROR IMAGE : Mirrors the image on vertical axis (left and right).

• OSD

> ENABLE TEXT OSD : Enables display of the Text typed in the TEXT field (displays bottom-right).

> ENABLE DATE&TIME OSD : Enables display of the Date & Time (displays top-left).



Basic | **OSD** | AGC | FFC | Thermal | VerticalView

☒ Enable text OSD

Text:

☒ Enable date&time OSD

Note

- The maximum length of OSD text is 16 characters.
- The available OSD characters are alphabet and numeric and + - = : ; , ' ? / ! ' ~ ! @ # \$ % * () [] < > { }

• AGC

The AGC controls the Automatic Gain Control (AGC) mode or algorithm along with selectable parameters.

> MODE :

- AUTOMATIC : Image contrast and brightness are optimized automatically as the scene varies. This mode provides an AGC which is based on a histogram-equalization algorithm and has been proven to offer the best image quality for the general scenes.

Full Menu Setup

- **MANUAL:** Image Contrast(gain) and Brightness(level) are entered completely manually. One-shot 'Brightness Adjustment' button offers the best brightness at a time.

[NOTE] In Manual mode, the brightness setting must be updated as the camera temperature changes. Manual mode is not recommended in an actual application.

- **LINEAR:** Image contrast and brightness(gain and level) optimized automatically based on scene statistics using a linear transfer function. Controls for the ITT Mean (sets gray scale midpoint) and Max Gain (AGC gain) are adjustable by entering the value in the Automatic Parameters section.

> **AUTO PRESET :** These presets apply only to the Automatic AGC algorithm and set predefined values that are stored in the Plateau Value and Max Gain. These presets have been empirically determined for different scenarios.

These settings are intended to be used as guidelines and are not guaranteed to be the optimum values for any particular scenario. It is recommended to fine-tune settings for preference and scene conditions.

> **CONTRAST :** Adjusts the contrast of the scene in Manual mode. Increasing the value increases the contrast.

> **BRIGHTNESS :** Adjusts the overall brightness of the scene in Manual mode. 'Brightness Adjustment' button gets one-shot brightness value.

> **FILTER :** Sets the refresh rate of the algorithm and determines how quickly the AGC will adjust to changes in the scene.

This ranges from 1 to 255 and higher number update faster.

Basic	OSD	AGC	FFC	Thermal	VerticalView
		Mode <input type="text" value="Automatic"/>			
		Auto Preset <input type="text" value="Default"/>			
		Contrast <input type="text" value="32 [Default]"/>			
		Brightness <input type="text" value="8192"/> <input type="button" value="Brightness Adjustment"/>			
		Filter <input type="text" value="64 [Default]"/>			
		SSO [%] <input type="text" value="15 [Default]"/>			
		ACE <input type="text" value="3 [Default]"/>			
		Plateau Level <input type="text" value="150"/>			
		Max Gain <input type="text" value="12"/>			

Full Menu Setup

> SSO [%] (The Smart Scene Optimization) :

SSO value defines the percentage of the histogram that will be allotted a linear mapping. Enabling this feature facilitates the avoidance of irradiance level compression, which is specifically important for bi-modal scenes. With SSO enabled, the radiometric aspects of an image are better preserved.

> ACE (The Active Contrast Enhancement) :

ACE feature provides a contrast adjustment dependent on the relative scene temperature. ACE thresholds greater than 0 impart more contrast to hotter scene content and decrease contrast for colder scene content (e.g. sky or ocean).

ACE threshold less than 0 do the opposite by decreasing contrast for hotter scene content and leaving more of the gray-scale shades to represent the colder scene content.


ACE can range from -8 to 8 where -8 decreases contrast in darker regions while +8 increases contrast in darker regions.

> PLATEAU LEVEL : The plateau ranges from 0 to 4095 and effects automatic and information based AGC modes.

> Max Gain : The Max Gain ranges from 0 to 255 and effects automatic, linear and information based AGC modes.

● FFC

Flat field correction(FFC) is a kind of the calibration process to update the image quality. FFC is recommended whenever the temperature transits across 0°C, 40°C, 65°C or the specific time period elapses. Video is frozen throughout the FFC event (nominally 0.5 sec) and resumes thereafter.



Basic OSD AGC **FFC** Thermal VerticalView

Mode Automatic

Do FFC!

Interval [frames]

FFC Interval 3600

Low Gain FFC Interval 1350

Temperature [0.1°C]

Temp Change 10

Low Gain Temp Change 10

Full Menu Setup

> MODE :

- **AUTOMATIC** : FFC is performed automatically with the shutter closed at the end of a specified period of time or whenever its temperature changes by a specified amount (whichever comes first) Time period can be set by the interval by means of number of video frames (33ms/frame in NTSC, 40ms/frame in PAL) between 0 and 30,000 frames, where the setting 0 disables the time triggered FFC.

[NOTE] Automatic mode is not recommended for shutterless configurations because there is no assurance that the core will be imaging a uniform source when it initiates an automatic FFC Low Gain apply to cameras that support Low Gain Mode, if used.

- **MANUAL**: FFC is performed automatically at start-up and only upon command 'Do FFC!' thereafter. If the image gets lost contrast and gets grainy, FFC is recommended by 'Do FFC!'. Repeated FFC events are necessary to correct for temperature drift in the camera. For this reason, it may be necessary to command FFC more frequently during startup or when the camera temperature changes quickly.

> INTERVAL [Frames] :

FFC INTERVAL sets the time period by means of the number of frames for the automatic FFC. LOW GAIN FFC INTERVAL sets the time period by means of the number of frames for the automatic FFC in low gain mode only.

> TEMPERATURE [0.1°C] :

TEMP CHANGES sets how much amount of temperature change will initiate the automatic FFC. LOW GAIN TEMP CHANGES sets how much amount of temperature change will initiate the automatic FFC in low gain mode only.

Full Menu Setup

• THERMAL

> SPOT METER: Spot Meter reads the temperature of the target at the center of the image.

- MODE : Sets the Spot Meter to display temperature in Fahrenheit, Celsius, or off. When Mode is ON, a blue spot appears at the center of image to aim the target.

- THERMOMETER :

Off - Does not display the temperature.

Digital - Displays a numerical temperature values.

Graph - Thermal Tab appears at the left of image.

Digital+Graph - Thermal Tab and the temperature values are displayed together.

- GET TEMPERATURE : Update the current temperature readings in Spot Meter.

> ISOTHERMAL: Isotherms are used to colorize the certain reason which has the specified temperature ranges.

- MODE : Sets ON or OFF.

- THRESHOLD UNIT : Defines the units to be used for the threshold settings.


Percentage - Sets the thresholds of each isotherm color region using percentage of the full dynamic range of the camera.

Degree - Sets the temperature threshold of each isotherm color region.

- UPPER / MIDDLE / LOWER THRESHOLD :

Defines the temperature thresholds for each regions to be colorized with the specific colors.

Ex) Regions with the temperature below Lower Threshold will be colorized with gray scale, with the temperature between Lower and Middle Threshold will be yellow scale, with the temperature between Middle and Higher Threshold will be orange to red scale and with the temperature above Higher Threshold will be the solid red.




The screenshot shows the 'Thermal' menu configuration. At the top, there are tabs: Basic, OSD, AGC, FFC, Thermal (active), and VerticalView. Below the tabs, the 'Spot Meter' section contains a 'Mode' dropdown menu set to 'On [Fahrenheit]', a 'Thermometer' dropdown menu set to 'Off', and an orange 'Get Temperature' button. Below this is the 'Isothermal' section, which includes a 'Mode' dropdown set to 'Off', a 'Threshold Unit' dropdown set to 'Percent [%]', and three input fields for thresholds: 'Upper Threshold' (95), 'Middle Threshold' (92), and 'Lower Threshold' (90).

Full Menu Setup


• **VerticalView**


- > MODE : ON displays the video in vertical view format, 16:9->9:16 for narrow streets, corridors or hallways.
- > ROTATION : Determines the orientation to rotate.

Viewer



Mode : On
Rotation : 90 degree





Basic

OSD

AGC

FFC

Thermal

VerticalView

Mode

On ▼

Rotation

90 degree ▼

View VerticalView video

Note

- The VerticalView function is valid on "H.264" video compression.

Full Menu Setup


3-2-4. Privacy Mask

Mark ENABLE checkbox to activate the privacy masks.

> COLOR : Select the color to mask at each privacy area.

> NAME : Input the individual name for each privacy mask.

Privacy Mask
⌵ ⌶ ⌵



☒ Enable

Color
⌵

Name

ID	Name	Delete
1	New	<input type="button" value="Delete"/>

Note

- The position of mask can be changed only if digital zoom and corridor function are inactive

To set the privacy mask (up to 8 privacy areas) :


- 1) Mark ENABLE checkbox.
- 2) In the video window, place the mouse cursor anywhere and click the right mouse button. A mini pop up appears.
Select CREATE MASK AREA / DELETE MASK AREA.
- 3) In the video window, place the mouse cursor where you would like to create a mask.
Click the left-mouse button to create (or delete) a mask. The mask window can be moved or resized with the mouse.
- 4) Enter the name in the list and then click SAVE.

Full Menu Setup

3-2-5. Digital Zoom

- > Mark **ENABLE** checkbox to activate the digital zoom.
- > **LEVEL** selects the fixed digital zoom ratio. X1.0 is not digital zoomed.

3-3. Audio




The screenshot shows the 'Audio' configuration page. On the left, a sidebar contains 'LIVE VIEW', 'PLAYBACK', 'SETUP' (with a gear icon), and 'USER MANUAL'. Under 'SETUP', there are links for 'Information', 'Video & Image', 'Audio' (highlighted), 'Record', 'Event', and 'System'. The 'Audio' page has a 'Save' button in the top right corner. The main content area is titled 'Audio' and includes the following settings:

- Enable**: A checked checkbox.
- Compression**: A dropdown menu set to 'G.711 u-law'.
- Sample rate [KHz]**: A dropdown menu set to '8'.
- Bitrate [Kbps]**: A dropdown menu set to '64'.
- Input Volume [dB]**: A dropdown menu set to '0.0'.
- Mute**: An unchecked checkbox.
- Enable output**: A checked checkbox.
- Output Volume [dB]**: A dropdown menu set to '0.0 [Default]'.
- Mute**: An unchecked checkbox.
- Audio auto activation on ONVIF access**: A checked checkbox.

- > Mark **ENABLE** checkbox to activate the audio. Supports full duplex audio.
- > **COMPRESSION** : Selects audio compression codec. μ -law is used primarily in North America and a-law used in most other countries outside North America. G.711 μ -law tends to give more resolution to higher range signals while G.711 a-law provides more quantization levels at lower signal levels.
- > **SAMPLE RATE** : Fixed at 8KHz by G.711.
- > **BITRATE** : Fixed at 64Kbps by G.711, the international standard for encoding wired-telephone audio.
- > Mark **INPUT MUTE** checkbox to mute the input from audio-in.
- > **INPUT VOLUME** : Adjusts the volume by the input signal level. -0.5dB reduces the volume about -6%, 0.0dB bypasses the signal without adjusting the volume and 3.0dB increases the volume about +41%.
- > Mark **ENABLE OUTPUT** checkbox to activate the audio. Supports full duplex audio.
- > Mark **OUTPUT MUTE** checkbox to mute the output to audio-out.
- > **OUTPUT VOLUME** : Adjusts the volume by the output signal level. -0.5dB reduces the volume about -6%, 0.0dB bypasses the signal without adjusting the volume and 3.0dB increases the volume about +41%.
- > **AUDIO AUTO ACTIVATION on ONVIF ACCESS** : If the checkbox to make Audio auto activation after reset or rebooting the camera to be compatible to ONVIF.

Full Menu Setup

3-4. Record



The screenshot shows the 'Record' setup menu. On the left is a sidebar with options: LIVE VIEW, PLAYBACK, SETUP (selected), USER MANUAL, and LOG OUT. The main area is titled 'Record' and has tabs for Record, Schedule, and Storage. A 'Save' button is in the top right. Under the 'Record' tab, there is a checkbox for 'Overwrite when storage is full'. Below it is a green 'Note' box stating: 'The record video codec supports only H.264 codec'. Further down is the 'Continuous Record Setting' section, which includes an 'Enable' checkbox and a 'Video stream' dropdown menu currently set to '2'.


3-4-1. Record

- > Mark OVERWRITE WHEN STORAGE IS FULL checkbox to allow the storage to be overwritten.
- > CONTINUOUS RECORD SETTING : Mark ENABLE checkbox to activate the continuous recording into the storage.
- > VIDEO STREAM : Selects the stream to be recorded into the storage.

[NOTE] SD, SDHC or SDXC memory can be used as a storage device.

Refer to manual for the suitable memory size from standard SD or micro SD.

3-4-2. Schedule



The screenshot shows the 'Schedule' setup menu. It has tabs for Record, Schedule (selected), and Storage. A checkbox 'Enable scheduled record' is checked. Below it is a calendar grid for scheduling recordings. The grid shows days of the week (Sun-Sat) and hours (0-23). The 'Mon' row is highlighted in orange, indicating a scheduled recording for that day. The 'Tue' row is also highlighted in orange, indicating a scheduled recording for that day. The 'Wed' row is highlighted in orange, indicating a scheduled recording for that day. The 'Thu' row is highlighted in orange, indicating a scheduled recording for that day. The 'Fri' row is highlighted in orange, indicating a scheduled recording for that day. The 'Sat' row is highlighted in orange, indicating a scheduled recording for that day.

Full Menu Setup

- > Mark ENABLE SCHEDULED RECORD checkbox to activate the scheduled recording into the storage.
- > Mark each box in time and day matrix when to be recorded.
It can be selected a time zone or day of the week.

3-4-3. Storage

- > **FORMAT** : Formats the storage. Backup the data before formatting the storage if necessary.
- > **REMOVE** : Helps removing the storage safely.

[NOTE]

Common Internet File System (CIFS) is a remote file access protocol that forms the basis for Windows file sharing, network printing, and various other network services. CIFS requires a large number of request/response transactions and its performance degrades significantly over high-latency WAN links such as the Internet. Network File System (NFS) is a network file system protocol, allowing a user on a client computer to access files over a network in a manner similar to how local storage is accessed. NFS, like many other protocols, builds on the Open Network Computing Remote Procedure Call (ONC RPC) system.

Record
Schedule
Storage

Format

Format the storage.

Remove

Remove and eject storage safely.

Storage Information

Status

Available

Total	Used	Available	Used Percent
7.41GB	7.19GB	222.55MB	97.07%

Full Menu Setup

3-5. Event

3-5-1. Triggers


EVENT TRIGGERS menu defines and sets the parameters for the various event sources.

[Important NOTE]

Once the event is generated, the camera can record the video into the storage, output the alarm signal, email the event, send the video clip to FTP, boost the video frame rate, move to PTZ preset or send the event to the notification server. These post processes require the settings at SETUP>EVENT>ACTIONS first and then SETUP>EVENT>RULES.

• Motion

- > Mark ENABLE checkbox to create & activate up to 4 motion areas.
- > NAME : Input the individual name for each motion detection area.
- > SENSITIVITY: Sets the motion detection sensitivity for all areas. Higher values increase sensitivity
- > DWELL : Sets the time for the motion event once detected.



The screenshot shows the 'Triggers' setup page for 'Motion' detection. The left sidebar contains navigation options: LIVE VIEW, PLAYBACK, SETUP (expanded), and USER MANUAL. The SETUP menu includes Information, Video & Image, Audio, Record, Event (expanded), Triggers (selected), Actions, Rules, and System. The main content area shows the 'Motion' tab with a video feed of a person walking, overlaid with a yellow motion detection area labeled 'default' and 'CAM1'. Below the video feed, there are input fields for 'Enable' (checked), 'Name' (default), 'Sensitivity' (80 [Default]), and 'Dwell [sec]' (3 [Default]). At the bottom, a table lists the configured motion areas.

ID	Name	Type	Dwell	Delete
1	default	Include	3	Delete

Full Menu Setup

To set the motion detection area (up to 4 include-types and 4 exclude-types) :

- 1) Mark ENABLE checkbox.
- 2) In the video window, place the mouse cursor where you would like to make a detection window and click&drag the right button. The following window is then generated.
 - INCLUDE-Type : defines areas where motion should be detected.
 - EXCLUDE-Type : defines areas within a window that should be ignored.
- 3) Enter a name and then click SAVE.

[NOTE]

Motion detection and VCA cannot be used simultaneously. If either one is enabled, the other one is disabled automatically.

● **VCA** (Video Contents Analysis)

- > Mark ENABLE checkbox to create & activate up to 3 VCAs(Line Cross & Field Intrusion).
- > NAME : Input the individual name for each VCA.
- > DIRECTION : (Line Cross only) Sets the direction of detection for the line cross.
 - TWO WAY : Detects the line cross in either way.
 - CW : Detects the line cross when crossed the line in the direction of arrow.
 - CCW : Detects the line cross when crossed the line in the direction of arrow.
- > COUNT : (Line Cross only) Displays the number of the object detections by the line cross detector.
- > RESET : Resets the count number.
- > DWELL : Sets the time for the event once detected.


To set the VCA detection area (up to total 3 VCAs including Line Cross & Field Intrusion) :

- 1) Mark ENABLE checkbox.
- 2) Click the mouse right button on the video viewer and a popup menu appears.
 - CREATE VCA DETECTOR : Select to create the VCA type, up to 3 VCAs.
 - LINE CROSS : Detects an object crossing the virtual line for the line cross detection.
 - FIELD INTRUSION : Detects objects entering or leaving the defined virtual window.
 - CREATE MASKING AREA : Select to create the masking area which will exclude the detection.
 - DELETE VCA DETECTOR : Deletes the existing VCA window. VCAs can be deleted at the list too.
 - DELETE MASKING AREA : Deletes the existing VCA mask window.
- 3) Enter a name and then click SAVE.

[NOTE]

Motion detection and VCA cannot be used simultaneously. If either one is enabled, the other one is disabled automatically.

Full Menu Setup



OBJECT SETTING

Sensitivity :

Width :

Height :

☒ Show object size

- Min. object size : 10 x 5 [px]

- Max. object size : 250 x 151 [px]

Enable

Name : New1

Dwell time [sec] : 3 [Default]

Direction : CW

Count : 2 Reset

ID	Name	Detector	Direction	Count	Dwell	Delete
1	New1	Line cross	CW	28	3	Delete

> OBJECT SETTING:

Click the green rotating icon on the top-right of the video window and OBJECT SETTING menu will appear. To hide it, click the icon again.

Mark SHOW OBJECT SIZE checkbox and a black rectangle at the top-left corner of the video window will appear. The black rectangle is the reference size which shows the minimum (white box) & maximum (black box) detecting size of the object. To adjust the minimum (or maximum) object size to be detected, adjust the left (right) ends of the slide bars, WIDTH & HEIGHT, by moving them with clicking and holding the left mouse button. Objects can be detected only for the object size set between minimum and maximum, that is, an object which is smaller than minimum or greater than maximum can't be detected. Too small value in MINIMUM or too big value in MAXIMUM for the object size might increase the erroneous detections.

Full Menu Setup

- **SENSITIVITY** : Sets the detection sensitivity for the objects.
- **WIDTH** : Sets the minimum/maximum sizes in width of the objects to be detected.
- **HEIGHT** : Sets the minimum/maximum size in height of the objects to be detected.
- **SHOW OBJECT SIZE** : Shows the reference size of detection object.

• **Tamper**

The camera can detect severe changes in the image caused by actions such as repositioning the camera or painting over of the lens and generates an alarm to alert.

- > Mark **ENABLE** checkbox to activate the tamper alarm.
- > **DWELL TIME** : Sets the time for the tamper alarm once detected.

• **Alarm In**

- > Mark **ENABLE** checkbox to input the alarm signal from the alarm-in port.
- > **TYPE** : Lets the camera know the type of alarm contacts, NO=Normally Open & NC=Normally Close.
- > **DWELL TIME** : Sets the time for the alarm once detected by the alarm-in.

• **System**


Used to trigger the event when the camera gets rebooted.

- > Mark **ENABLE** checkbox to activate the system event.
- > **DWELL TIME** : Sets the time for the alarm once the system event is detected.

• **Manual**

Enables to user to set the event trigger optionally.

- > Mark **ENABLE** checkbox to enable the manual trigger icons on the live view menu.
- > **DWELL TIME** : Sets the time for the event once triggered by the manual trigger on the live view menu.



The screenshot shows the 'Full Menu Setup' interface with the 'Manual' tab selected. The interface has a top navigation bar with tabs: Motion, VCA, Tamper, Alarm In, System, Manual (active), Network, Timer, and Temperature. Below the tabs, there are two sections for manual triggers. Each section has an 'Enable' checkbox and a 'Dwell time [sec]' dropdown menu set to 3. The first section is labeled 'Manual Trigger1' and the second is labeled 'Manual Trigger2'.


Full Menu Setup

• Network

Used to trigger the event when the network connection fails.

> Mark ENABLE checkbox to activate the network event.

> DWELL TIME : Sets the time for the event once triggered by the network connection event.




Motion VCA Tamper Alarm In System Manual **Network** Timer Temperature

☐ Enable

Dwell time [sec] 3

• Timer

Mark ENABLE checkbox to trigger the event as defined Timer Interval.



Motion VCA Tamper Alarm In System Manual Network **Timer** Temperature

☒ Enable

Timer Interval


Hour 1

Minute 0

Second 0

• Temperature

Mark ENABLE checkbox to trigger the event as defined Temperature.



Motion VCA Tamper Alarm In System Manual Network Timer **Temperature**

☒ Enable

Dwell time [sec] 3

☐ Enable triggering on High Limit

Temperature [°C] 60

☐ Enable triggering on Low Limit


Temperature [°C] -20

Full Menu Setup

- > DWELL TIME : Sets the time period to be continued for the alarm process once the temperature limit is detected.
- > ENABLE TRIGGERING HIGH / LOW LIMIT : Mark the checkbox to enable and set the temperature limits to trigger the events by the defined Temperature high or low limit.

3-5-2. Actions

EVENT ACTIONS menu defines and sets the parameters for how to treat the various event sources.



• Record

- > Mark ENABLE checkbox to enable recording into the built-in storage when the event occurs.
- > VIDEO STREAM : Selects the stream to be recorded when the event occurs.
- > RECORDING TIME : Sets the length of time to record after the event.
- > PRERECORDING TIME : Sets the length of time to record before the event.

• Alarm Out

- > Mark ENABLE checkbox to output the alarm signal to the alarm-out port.
- > TYPE : Selects the type of alarm contacts, NO=Normally Open & NC=Normally Closed. Alarm-out port is not an actual relay contact but outputs 0V for Low level & 3.3V for High level with the current driving capacity of 50mA max.

Full Menu Setup

• E-mail

The camera can send email messages generated by the events via SMTP (Simple Mail Transfer Protocol).

> Mark **ENABLE** checkbox to enable emailing.

- **SENDER** : Enter the email address as the sender. Any virtual email address like sample@sample.com can be used if the recipient can recognize it from the camera.
- **INTERVAL** : Sets the interval for emailing after the events occur.
- **AGGREGATE EVENTS** : Sets the number of events which will be sent in an email.

Record
Alarm Out
E-Mail
FTP
Video Boost
Notification Server

☐ **Enable**

Sender

Interval [1... 86400] sec

Aggregate events [1... 100] EA

☐ **Use mail server**

Mail server

Port

☐ **Enable use(SMTP) authentication**

User name

Password

Login method

Receiver List

Receiver1	<input type="text"/>	Receiver2	<input type="text"/>
Receiver3	<input type="text"/>	Receiver4	<input type="text"/>
Receiver5	<input type="text"/>	Receiver6	<input type="text"/>
Receiver7	<input type="text"/>	Receiver8	<input type="text"/>

E-Mail(SMTP) Test

Receiver

Full Menu Setup

- > Mark USE MAIL SERVER checkbox to set the mailing server.
 - MAIL SERVER : Enter the host name or IP addresses for the mail servers. If a host name is used, a valid DNS server must be specified in the Network-Basic settings.
 - PORT : Enter the port number of the mail server.
- > Mark ENABLE USE(SMTP) AUTHENTICATION checkbox if the mail server requires authentication.
 - USER NAME : Enter the user name as provided by the network administrator.
 - PASSWORD : Enter the password as provided by the network administrator.
 - LOGIN METHOD : Select one for SMTP authentication method allowed.

[NOTE] If a PLAIN or LOGIN mechanism is negotiated, the camera sends the user name and password to the SMTP server. The LOGIN mechanism is supported by Microsoft, as well as some other clients. Most other clients support the PLAIN authentication mechanism. Since the vast majority of Email clients support only PLAIN or LOGIN, mail server administrators will probably want to consider using STARTTLS to provide an encryption "tunnel" between the client and server to protect the user name and password.
- > RECEIVER LIST : Enter the recipient's email addresses as the receivers.
- > E-MAIL(SMTP) TEST : Enter the recipient's email address in RECEIVER and click the TEST button to test if the mail servers are functioning and the email address is valid.

• **FTP**

FTP notification will save files on the specified FTP server.

- > Mark ENABLE checkbox to set the FTP server.
 - SERVER : Enter the IP address or host name of the specific FTP server.
 - PASSIVE MODE : Under normal circumstances the network camera simply requests the target FTP server to open the data connection. Checking this box issues a PASV command to the FTP server and establishes a passive FTP connection; whereby the network camera actively initiates both the FTP control and data connections to the target server. This is normally desirable if there is a firewall between the network camera and the target FTP server.
 - PORT : Enter the port number used by the FTP server. The port number can be adjusted in the range 1-65535. The default setting is 21.
 - REMOTE DIRECTORY: Specify the path to the directory where the uploaded images will be stored. If this directory doesn't already exist on the FTP server, an error message shows up when uploading.
 - USER NAME: Enter the user name provided by the network administrator.
 - ANONYMOUS LOGIN: Mark ANONYMOUS LOGIN checkbox if anyone is permitted to access the FTP server.
 - PASSWORD: Enter the password provided by the network administrator.

Full Menu Setup

> JPEG SETTING : Configures JPEG for the FTP server.

- PRE-EVENT : Sets the time & the frame rate for JPEG images to be sent to FTP before the event.
- POST-EVENT : Sets the time & the frame rate for JPEG images to be sent to FTP after the event.
- PREFIX FILE NAME : Input the prefix for JPEG image file names to be sent to FTP.
- ADDITIONAL SUFFIX : Selects the suffix for JPEG image file names to be added after the file name. Selecting NONE will overwrite the previous file and thus DATE & TIME is most preferable.

Record
Alarm Out
E-Mail
FTP
Video Boost
Notification Server

☐ Enable

Server

☐ Passive mode

Port

Remote directory

User name

☐ Anonymous login

Password

JPEG Setting

Pre-event
 [sec]
 [fps]

Post-event
 [sec]
 [fps]

Prefix file name

Additional suffix
☐ None
☒ Date&Time
☐ Sequence number

Full Menu Setup

• Video Boost

Sets the frame rate and bitrate for H.264 stream and the quality for JPEG stream at EVENT STATE when the event occurs.

[NOTE] Video boost is disabled during SD recording.

Record
Alarm Out
E-Mail
FTP
Video Boost
Notification Server

Video Boost 1

☐ Enable

	Normal State	Event State
Frame rate	12.5	12.5 <input type="button" value="v"/>
Bitrate	6000	6000 <input type="button" value="v"/>

Video Boost 2

☐ Enable

	Normal State	Event State
Frame rate	12.5	12.5 <input type="button" value="v"/>
Bitrate	2000	2000 <input type="button" value="v"/>

Video Boost 3

☐ Enable

	Normal State	Event State
Quality	60	60 <input type="button" value="v"/>

Full Menu Setup

• Notification Server

- > Mark ENABLE checkbox to notify the event to the notification server when it occurs.
 - TYPE : Selects the network protocol to connect the notification server.
 - SERVER URL : Input the server URL of the notification sever. To enable the audio when the event occurs, copy the URL at SETUP>AUDIO and paste it on the server URL like `http://x.x.x.x/setup/audio/audio.php`
 - USERNAME : Enter the username (default : admin)
 - PASSWORD : Enter the password (default : admin)
- > NOTIFICATION TEST: Input the test message and click TEST button.

[NOTE]

There could be several event actions like FTP, e-mail etc. For detailed URL per event actions, refer to API documents. In case Notification server is set as event rule, the same URL from Notification Test should be entered in RULE>ADD>NOTIFICATION SERVER.

Record
Alarm Out
E-Mail
FTP
Video Boost
Notification Server

Enable

Type

▼

Server URL

Username

Password

Notification Test


Message

Test

Full Menu Setup

3-5-3. Rules

EVENT RULES menu defines and sets the parameters for what to do for the various event sources.



• **Event Processing**

Event process lists have to be generated and can be edited for what to do when the event occurs. List shows the rule name, trigger source and type of action for each event process. To edit or delete the rule in the list, click the listed line and then click EDIT or DELETE button.

ADDing & EDITing RULES

> NAME : Input the rule name which is descriptive to the rule.

EVENT TRIGGER

> TYPE : Select the type of the event source.

> AND : Mark ENABLE checkbox to trigger the event when two TYPES of event occur within the defined dwell time of the individual events.

EVENT ACTION

> ALARM OUT : Mark the checkbox to activate the alarm-out port, if available, as set in SETUP>EVENT> ACTIONS>ALARM OUT when the selected event occurs.

> E-MAIL :

- Input the email addresses to be emailed.

- Mark the checkbox for the email addresses to be emailed as set in SETUP>EVENT> ACTIONS>E-MAIL when the selected event occurs

- SUBJECT of email is a required field and ADDITIONAL INFO is optional to input.

> NOTIFICATION SERVER: Mark the checkbox to use the notification server as set in SETUP>EVENT> ACTIONS> NOTIFICATION SERVER when the selected event occurs.

Full Menu Setup

- MESSAGE : Input the message to be sent to the notification server.
- > FTP : Mark the checkbox to use FTP as set in SETUP>EVENT>ACTIONS>FTP when the selected event occurs.
- > VIDEO BOOST : Select the video stream to be boosted up.
[NOTE] Video boost is disabled if RECORD is enabled.
- > RECORD : Mark the checkbox to record the image into the built-in storage, if available, as set in SETUP>EVENT>ACTIONS>RECORD when the selected event occurs.

Add Rule

Name

Event Trigger

Type System ☒ AND System

Event Action

☐ Alarm out

☐ E-Mail

☐ Address1

☐ Address3

☐ Address5

☐ Address7

☐ Address2

☐ Address4

☐ Address6

☐ Address8

Subject

Additional info

☐ Notification Server

Message

☐ FTP

Video Boost ☐ Video1 ☐ Video2 ☐ Video3

Note

• Please note that Video Boost does not work during SD recording

☒ Record

OK
Close

Full Menu Setup

• ONVIF Mapping

Onvif mapping is provided to map the various events generated by this camera, but not defined by Onvif, to assign them to Onvif events for the Onvif compatible VMSeS or NVRs. Two mappings for Motion and Alarm In are provided to be mapped and can be used by editing them.


For example, any of the selected items in tns1:VideoSource/MotionAlarm will notify the Onvif compatible VMSeS or NVRs as Motion Alarm. In the same way, any of the selected items in tns1: Device/Trigger/Digital Input will notify the Onvif compatible VMSeS or NVRs as Alarm IN.

Event Processing		
ONVIF Mapping		
#	Event Topic	Event Notification
1	tns1:VideoSource/MotionAlarm	Motion Detection <input type="button" value="Edit"/>
2	tns1:Device/Trigger/DigitalInput	Network Loss <input type="button" value="Edit"/>

Full Menu Setup

3-6. System

3-6-1. Security



The screenshot shows the 'Security' configuration page. On the left is a sidebar with a 'SETUP' menu containing options like Information, Video & Image, Audio, Record, Event, System, Security (highlighted), Date & Time, and Network. The main area is titled 'Security' and has a breadcrumb 'SETUP / System / Security'. A 'Save' button is in the top right. Below the title are tabs for 'Users', 'HTTPS', 'IP Filter', 'ONVIF', 'Video Stream', and 'Export / Import'. The 'Users' tab is active, showing a checkbox for 'Enable anonymous viewer login' and a table of users.


#	Name	Group	Authority
1	admin	administrator	live, setup, system

At the bottom of the table are 'Add', 'Edit', and 'Delete' buttons.

• Users

Manages the user accounts by names, groups and authorities.


- > Mark ENABLE ANONYMOUS VIEWER LOGIN if anyone is permitted to login anonymously. Accessing SETUP menu with the anonymous login will exit and require ID/Password login.
- > USERS : Can be added, edited or deleted.



The 'Add User' dialog box contains the following fields:

- Name:** A text input field with the placeholder 'Name'.
- Password:** A text input field with the placeholder 'Password'.
- Confirm Password:** A text input field with the placeholder 'Password'.
- Group:** A dropdown menu with 'guest' selected.

At the bottom are 'OK' and 'Close' buttons.



The 'Edit User' dialog box contains the following fields:


- Name:** A text input field with 'admin' entered.
- Password:** A text input field with the placeholder 'Password'.
- Confirm Password:** A text input field with the placeholder 'Password'.
- Group:** A dropdown menu with 'administrator' selected.

At the bottom are 'OK' and 'Close' buttons.

Full Menu Setup

• HTTPS

Selects the CONNECTION MODE.



Users **HTTPS** IP Filter ONVIF Video Stream Export / Import

Connection mode HTTP&HTTPS


- > HTTP : Transfers data without encryption. Supports a URL that only starts with "HTTP: "
- > HTTPS : Transfer data with encryption by Hypertext Transfer Protocol over SSL protocol. Supports a URL that only starts with "HTTPS: "
- > HTTP&HTTPS : Supports both HTTP and HTTPS protocols.

[NOTE]

To ensure security on the internet, all web browsers provide several security levels that can be adjusted for sites that use SSL (Secure Socket Layer) technology to transfer data. SSL encrypts communications, making it difficult for unauthorized users to intercept and view user names and passwords. SSL requires signed certificates to determine if the web browser accessing the camera has the required authentication. This camera can generate a self-signed certificate using Open SSL.

• IP Filter

- > Mark ENABLE IP ADDRESS FILTERING to filter the IP addresses.
- > Mark ON/OFF for the IP address range to use IP filtering.
- > Select ALLOW or DENY to permit or filter out the IP address range.
- > Input the IP address ranges with START IP and END IP.



Users HTTPS **IP Filter** ONVIF Video Stream Export / Import

☐ Enable IP address filtering

On/Off	Priority	Policy	Start IP	End IP
<input type="checkbox"/>	1	ALLOW <input type="checkbox"/>	0 . 0 . 0 . 0	0 . 0 . 0 . 0
<input type="checkbox"/>	2	ALLOW <input type="checkbox"/>	0 . 0 . 0 . 0	0 . 0 . 0 . 0
<input type="checkbox"/>	3	ALLOW <input type="checkbox"/>	0 . 0 . 0 . 0	0 . 0 . 0 . 0
<input type="checkbox"/>	4	ALLOW <input type="checkbox"/>	0 . 0 . 0 . 0	0 . 0 . 0 . 0
<input type="checkbox"/>	5	ALLOW <input type="checkbox"/>	0 . 0 . 0 . 0	0 . 0 . 0 . 0

Full Menu Setup


[NOTE] To add a subnet of network addresses, these must be added in CIDR (Classless Inter-Domain Routing) notation. For example: entering 192.168.1.0/24 will add all the addresses in the range 192.168.1.1 to 192.168.1.254. Contact your network administrator for more detail. If the network camera is accessed via a proxy server, the IP address for the proxy server must be added as an allowed address.

• ONVIF

> Mark ENABLE WS SECURITY to provide the ONVIF compliance.

• Video Stream

- > ENABLE RTSP AUTHORIZATION : If marked, the authorization is required when the stream 1/2/3 is accessed using RTSP.
- > ENABLE JPEG SNAPSHOT AUTHORIZATION : If marked, the authorization is required when the Jpeg snapshot image is requested.
- > ENABLE JPEG/HTTP PUSH AUTHORIZATION : If marked, the authorization is required when the Jpeg/HTTP PUSH image is requested.




• Export / Import

- > Mark ENABLE ENCRPTION FOR EXPORT AND IMPORT FILE :
System configuration file, which is exported at SETUP>SYSTEM>MAINTENANCE>SETUP EXPORT, is encrypted with the password herein.

[NOTE] THIS PASSWORD MUST BE USED when System configuration file is imported by other cameras if the file was exported with the password.

- > If the checkbox is not marked, system configuration file is exported without encryption.



Full Menu Setup

3-6-2. Date & Time

● **Current Time**

Shows the current date and time. Clicking SAVE tap updates and saves the date and time with the selected time in NEW TIME.

● **New Time**

Select one of the following server times.


- > SYNCHRONIZE WITH COMPUTER TIME : Obtains the time from the computer.
- > SET MANUALLY : Sets the date and time manually.
- > SYNCHRONIZE WITH NTP SERVER : Obtains the time from the assigned NTP server at every hour in INTERVAL. The NTP server's IP address or host name has to be specified in the time server.

● **Time Zone**

Select the time zone to be referenced to the NTP server where the camera is installed. Mark AUTOMATICALLY ADJUST FOR DAYLIGHT SAVING CHANGES check box to update the time automatically with daylight savings.

● **Date & Time Display**

Select the date & time formats to be displayed.



The screenshot displays the 'Date & Time' configuration screen. On the left is a sidebar menu with options: LIVE VIEW, PLAYBACK, SETUP (selected), and USER MANUAL. The main area is titled 'Date & Time' and includes a 'Save' button. It is divided into three sections: 'Current Time' (showing Date: 01-01-1970, Time: 23:57:25), 'New Time' (with 'Synchronize with computer time' selected, showing Date: 13-01-2016, Time: 17:04:23), and 'Time Zone'. The 'New Time' section also has a 'Set manually' option (unselected) showing Date: 01-01-1970, Time: 23:57:10, and a 'Synchronize with NTP server' option (unselected) showing Server: 0.pool.ntp.org and Interval: 12 hours.

Full Menu Setup

3-6-3. Network

• TCP/IP

> IPv4 ADDRESS :


- OBTAIN IP ADDRESS VIA DHCP : Gets the IP address assigned by the DHCP (Dynamic Host Configuration Protocol) server.
- STATUS : 'Allocated' shows that the IP address is obtained from the DHCP.
- IP ADDRESS, SUBNET MASK, GATEWAY : Displays the current IP address which is obtained from the DHCP.
- USE THE FOLLOWING ADDRESS : Requires the input of a static IP address manually.

> IPv6 ADDRESS : Mark ENABLE check box to use IPv6 address and click SAVE button, then new IPv6 address will be obtained.

> DNS :

- OBTAIN DNS ADDRESS VIA DHCP SERVER : Obtains the DNS address automatically assigned by DHCP server.
- USE THE FOLLOWING DNS ADDRESS : Requires manual input as per below.
 - DOMAIN NAME : Enter the domain for the host name
 - PRIMARY DNS SERVER : Enter the IP address of the primary DNS server.
 - SECONDARY DNS SERVER : Enter the IP address of the secondary DNS server.

> HOSTNAME : This camera can be accessed using a host name instead of an IP address. The host name is usually the same as the assigned DNS name.



The screenshot shows the 'Network' setup page. The left sidebar contains a menu with 'LIVE VIEW', 'PLAYBACK', and 'SETUP'. Under 'SETUP', there are options for 'Information', 'Video & Image', 'Audio', 'Record', 'Event', 'System', 'Security', 'Date & Time', 'Network' (highlighted), 'Language', and 'Maintenance'. The main content area is titled 'Network' and has a breadcrumb trail 'SETUP / System / Network'. A 'Save' button is in the top right. Below the title, there are tabs for 'TCP/IP', 'DDNS', 'RTP', 'UPnP', 'Zeroconf', and 'Bonjour'. The 'TCP/IP' tab is active, showing the 'IPv4 Address' section. In this section, the 'Obtain IP address via DHCP server' option is selected with a radio button. Below this, the 'Status' is 'Allocated'. The 'IP address' is displayed as 192.168.0.87, the 'Subnet mask' as 255.255.255.0, and the 'Gateway' as 192.168.0.1. At the bottom of the section, the 'Use the following IP address' option is unselected.

Full Menu Setup

IPv6 Address

☐ Enable

IPv6 address

fe80::7ac2:c0ff:fe20:142/64

DNS

☐ Obtain DNS address via DHCP server

☒ Use the following DNS address

Domain name

Primary DNS

168

126

63

1

Secondary DNS

0

0

0

0

Hostname

Hostname

RNP-XE3DIP2812M-IR78C2C0200142

Port

HTTP port

80

HTTPS port

443

RTSP port

554

> PORT :

- HTTP PORT : Use a port number in the range 1024-65535. Default is 80.
- HTTPS PORT : Use a port number in the range 1024-65535. Default is 443.
- RTSP PORT : Use a port number in the range 1024-65535. Default is 554.

Full Menu Setup

- **DDNS** (Dynamic Domain Naming Service)

- > Mark ENABLE checkbox to use DDNS.
- > DDNS server : Select the DDNS server to use.
- > Input REGISTERED HOST name, USER NAME, PASSWORD and INTERVAL.

[NOTE]

If the camera has not been registered to the DDNS host previously, the registration is required. If the camera is already registered but its IP address changes, the DDNS must be updated with this new IP address. It will update at a regular interval.

TCP/IP	DDNS	RTP	UPnP	Zeroconf	Bonjour
--------	-------------	-----	------	----------	---------

☐ **Enable**

DDNS server

dyndns.org

▼

Registered host

User name

Password

Confirm password

Interval

1 hour

▼

Full Menu Setup

• RTP

- > **START PORT & END PORT** : RTP port range defines the range of the ports from which ports of the video/audio are automatically selected. This feature is useful if the camera is connected to a NAT router with manually configured port mapping. Limit the range of the ports permitted for RTP unicast/multicast by entering START PORT and END PORT.
- > **MULTICAST - STREAM1, 2, 3** : Only IP addresses within certain ranges can be used for multicasting. The camera has been pre-configured with addresses from these ranges and does not normally need to be reconfigured. If an address needs to be changed, please contact the network administrator.
 - Mark **ENABLE** checkbox to use the multicast for each stream.
 - **DESTINATION IP**: Type IP address in the range. Multicast addresses are allocated according to these IANA policies.
 - **PORT** : Use the port number in the range 1024-65532. Default is 4000.
 - **TTL** : When IP packets or data fails to be delivered to the destination within TTL (Time To Live), this setting tells the network router when to discard the packet. The value is usually measured in 'hops', i.e. the number of network routers that can be passed before the packet arrives at its destination or is dropped.

TCP/IP	DDNS	RTP	UPnP	Zeroconf	Bonjour
<div> <div>Start port</div> <div>30000</div> <div>[30000... 39800; Only even values are available]</div> </div> <div> <div>End port</div> <div>30199</div> </div>					
<div>Multicast - Stream 1</div> <div> <input type="checkbox"/> Enable </div> <div> <div>Destination IP</div> <div>231 . 1 . 128 . 20</div> <div>[224.0.0.0... 239.255.255.255]</div> </div> <div> <div>Port</div> <div>40000</div> <div>[1024... 65530; Only even values are available]</div> </div> <div> <div>TTL</div> <div>1</div> <div>[1... 255]</div> </div>					
<div>Multicast - Stream 2</div> <div> <input type="checkbox"/> Enable </div> <div> <div>Destination IP</div> <div>231 . 1 . 128 . 21</div> <div>[224.0.0.0... 239.255.255.255]</div> </div> <div> <div>Port</div> <div>40000</div> <div>[1024... 65530; Only even values are available]</div> </div> <div> <div>TTL</div> <div>1</div> <div>[1... 255]</div> </div>					
<div>Multicast - Stream 3</div>					

Full Menu Setup


• UPnP

UPnP is enabled by default so that the network camera can be automatically detected by operating systems and clients that support this protocol.

> FRIENDLY NAME : Enter the name up to 32 alphanumeric characters like Model Name-MAC address.

[NOTE]

UPnP must also be enabled on your Windows computer. To do this, open the Control Panel from the Start Menu and select Add/Rename programs. Select Add / Remove Windows Components and open the Networking Services section. Click Details and then select UPnP as the service to add.



TCP/IP DDNS RTP **UPnP** Zeroconf Bonjour

☒ Enable

Friendly name XXX-XXXXXX

• Zeroconf

ZeroConf (Zero configuration) networking enables the network to establish automatically with the automatic assignment of numeric network addresses (zeroconf IP addresses) without requiring manual operator intervention or special configuration servers when the DHCP server is not available in the network.

> Mark ENABLE to use ZeroConf networking.

> ZeroConf ADDRESS : 169.254.xxx.xxx as default.




TCP/IP DDNS RTP UPnP **Zeroconf** Bonjour

☒ Enable

Zeroconf address 169.254.100.181

• Bonjour

Bonjour is Apple's implementation of zero-configuration networking (zeroconf), a group of technologies that includes service discovery, address assignment, and hostname resolution.



TCP/IP DDNS RTP UPnP Zeroconf **Bonjour**

☒ Enable

Friendly name XXX-XXXXXX-78C2C0200142

Full Menu Setup

3-6-4. Language

Six languages are available to select from English, Deutsch (German), Français (French), Polski (Polish), Suomi (Finnish), and 한국어 (Korean).

3-6-5. Maintenance

Maintenance

SETUP / System / Maintenance

Maintain

Restart

Restart the unit.

Reset

Resets all parameters to the original factory settings, except the IP address and PTZ configurations.

Default

Resets all parameters to the original factory settings.

Upgrade

Upgrade the unit with the new firmware.

Drop file here or click to upload

Upgrade

Setup Export

Save all parameters and user-defined script to a export file.

Export

Setup Import

Import configurations from exported file.

Drop file here or click to upload

Import

● **Maintain**

- > **RESTART** : Restarts the camera without changing any settings.
- > **RESET** : Restarts and loads the factory settings but does not change IP address and PTZ settings.
- > **DEFAULT** : Loads and saves the factory defaults for all parameters including IP address and PTZ settings.

[CAUTION]

Do not disconnect the power or network cable during RESET or DEFAULT operations.

Full Menu Setup

• Upgrade

Bring the firmware file to the drop box or click the drop box to browse for the firmware file, and then click the UPGRADE button.

[**CAUTION**] Do not disconnect the power or network cable during firmware UPGRADE.

• Setup Export

Current configurations for the camera can be saved as a file by clicking the EXPORT button.

• Setup Import

The exported configuration file from a reference camera or a backup configuration can be imported and configured/reloaded onto other cameras.

[NOTE]

- SETUP EXPORT/SETUP IMPORT can only be used on the same camera models with the same firmware. This feature is not intended for the configuration of multiple units or for firmware upgrades.
- When the encrypted System configuration file with the password is imported, type the password at SETUP>SYSTEM>SECURITY>EXPORT/IMPORT with the SAME password which was used in exporting the system configuration file from the reference camera. Otherwise, 'INVALID FILE' error appears.

3-6-6. Logs & Report

• Logs

The log file records the story into the unit since the system restarts.

> DATABASE CAPACITY: Shows the useable system memory space for Log file.


> SEARCH CONDITION: Allows you to search the log as per the type. E.g. System, Access, Event and Media, Start-End date and Start-End time.

> LOG LIST: Shows the logs as per the search.

• Report

Provides overall information about the server status.

4. USER MANUAL



Help the menu function.

Click and pop-up the page about current menu description.

Troubleshooting

If you suspect a problem is being caused by incorrect configuration or some other minor problem, consult the troubleshooting guide below.

Upgrading the Firmware

Firmware is software that determines the functionality of the network camera.

One of your first actions when troubleshooting a problem should be to check the current firmware. The latest version may contain a correction that fixes your particular problem. The current firmware version in your camera is displayed on the Basic Configuration or About. For the latest firmware of the camera, please contact with your product administrator.

Detailed instructions on how to perform the upgrade process are provided with each new release.

General Troubleshooting

The following list covers some of the problems that may be encountered and suggests how to remedy them:

Symptom	Guide
The camera cannot be accessed by some clients.	If using a proxy server, try disabling the proxy setting in your browser. Check all cabling and connectors.
The camera works locally, but not externally	Check if there are firewall settings that need to be adjusted. Check if there are router settings that need to be configured.
Poor or intermittent network connection.	If using a network switch, check that the port on that device uses the same setting for the network connection type (speed/duplex).
The camera cannot be accessed via a host name.	Check that the host name and DNS server settings are correct.
Not possible to log in.	When HTTPS is enabled, ensure that the correct protocol (HTTP or HTTPS) is used. When attempting to log in, you may need to manually type in http or https in the browser's address bar.
No image using Refresh and/or slow updating of images.	If images are very complex, try limiting the number of clients accessing the camera.
Images only shown in black & white.	Check the Video & Image setting.
Blurred images.	Refocus the camera.

Troubleshooting

Poor image quality.	Increased lighting can often improve image quality. Check that there is sufficient lighting at the monitored location. Check all image and lighting settings.
Rolling dark bands or flickering in image.	Try adjusting the Exposure Control setting under AE and AWB part.
H.264 not displayed in the client.	Check that the correct network interface is selected in the Video & Image/Stream.
Multicast H.264 not displayed in the client.	Check with your network administrator that the multicast addresses used by the camera are valid for your network. Check that the Enable multicast checkbox are enabled in the System/Network/RTP tab. Checks with your network administrator to see if there is a firewall preventing viewing.
Multicast H.264 only accessible by local clients.	Check if your router supports multicasting, or if the router settings between the client and the server need to be configured. The TTL value may need to be increased.
Color saturation is different in H.264 and Motion JPEG.	Modify the settings for your graphics adapter. Please see the adapter's documentation for more information.
Poor audio quality.	Too many users/clients connected to the camera may affect the sound quality adversely. Try limiting the number of clients allowed to connect.
Distorted audio.	Check that the correct Audio Input source is selected. Select Microphone for a connected external microphone. Select Line for a connected line in source.

[NOTE]

If you cannot find the help you require, please see the User's Manual, or contact with your network administrator.



eneo® is a registered trademark of
VIDEOR E. Hartig GmbH
Exclusive distribution through specialised
trade channels only.

VIDEOR E. Hartig GmbH
Carl-Zeiss-Straße 8
63322 Rödermark/Germany
Tel. +49 (0) 6074 / 888-0
Fax +49 (0) 6074 / 888-100
www.videor.com
www.eneo-security.com

Technical changes reserved

© Copyright by VIDEOR E. Hartig GmbH
Version 05/2018